

K & M Amusements Inc.
2206 S. Main Suite 2 Maryville, Mo 64468
www.kmamusements.com 1-660-582-5929

Delivery & Pickup: K&M Amusements Inc. will deliver and set up equipment at time and location agreed on. No Equipment is to be taken apart or moved to another location unless K&M Amusements gives lessee specific permission to do so. Lessee may pickup and return equipment if approved by a K&M Amusements Inc. representative.

Deposit is to be made at time of signing this agreement & payment made upon delivery or pickup. No refunds will be given unless K&M Amusements inc. agree to refund and may not refund deposit unless said equipment can be rented for that time in which the lessee was going to have that equipment for. When lesser cannot get to equipment on time agreed or if lessee does not return equipment on or before time agreed, than lessee may lose deposit or be charged for an extra day or (days) rental. Deposit will be refunded after all equipment is checked and found to be in satisfactory condition, no damage is found on any of the equipment, no food/drink/face-paint messes and is returned on time.

Inflatable Guidelines: Electrical service==Must have 1 (20amp breaker) per blower. Products will be used on smooth flat surfaces such as grass or a hard surface such as smooth concrete or gym floor. K&M Amusements will not be held liable for damage done to any surface on which equipment is placed. Equipment will not be placed on gravel, rock, mud, landscaping mulch, bricks, or any jagged surface. The unit must not be located next to walls, poles, under trees, or any fixed objects. A minimum of 4 ft. clearance on all sides must be observed at all times. Proper ext. cords will be used if needed and will be furnished by K&M Amusements Inc. if needed.

Operation: Adult supervision is required at all times. Do not assemble, disassemble, operate or play with inflatable while under the influence of alcohol or drugs. Observe and obey rules posted on unit. Lessee is responsible for all equipment rented from the time of receipt until the time of return. If you discover something broken or missing, please notify us at once so we may make note of items in question and prevent loss of deposit or replacement costs of items. Compatible age groups must play on equipment at the same time. Age groups must not be mixed.

All persons must remove shoes before playing on inflated equipment. Any person with back, neck or other health problems should not use this equipment.

(ANYONE WITH HISTORY OF EPILEPTIC SEIZURES SHOULD AVOID THE LASER TAG UNIT DUE TO FLASHING STROBE LIGHTS)

NO one under the age of 18 is to be allowed inside the Dunk Tank. INITIAL: _____

Terms of Lease: The lessee or using party shall be in charge of operation, and is fully responsible for operation after receiving the unit. Lesser is not responsible for any injuries occurring to lessee or to any persons using the leased property. Lessee further agrees to hold lesser free and harmless against any claims and further. Lesser shall be indemnified for all cost incurred due to claims from anyone; including court cost, attorney fees, and other related costs involving the use of leased equipment. Lessee shall provide own liability insurance unless otherwise specified. Lessee is responsible for the replacement value of the leased object in the event of theft, vandalism, fire, or any act that may damage or destroy the leased property.

Payment and check policy: If it is determined by lesser that payment has not been received or that lesser equipment is not being operated safely in and accordance with the terms of this agreement, then all rented items will be picked up before time arranged and all equipment is immediately due to be returned to lesser. Rentals must be paid in full by cash or check. If paying by check and bank returns check unpaid the lessee (when notified) must pay in cash the amount of check plus a \$25 fee at lesser office within two days. Otherwise, check will be turned to an attorney for collection with an extra charge of \$50 and all legal cost will be due.

Inflatable Rules: Never jump or play on partially inflated unit. Do not allow riders to play or climb on outside of walls, sides, or roof of unit. Always follow # of riders recommended. Do not plug or unplug motor repeatedly as it will cause damage to motor. Never put hose or water on unit unless unit is designed as a water unit. In case of rain or high winds, remove riders and unplug motor. Always have an adult present to supervise riders. Do not allow riders to pull nettings or columns. Do not allow flips or horseplay in units. Do not allow any animals in or on units. Do not allow the use of silly string, candy, gum, body paints, or food/drink of any kind around or in the unit. Do not hang any objects inside unit, such as balloons, piñatas, streamers, etc. Equipment such as pool tables, foosball tables, dart games, video games etc. will be only used in locations indoors, NOT OUTDOORS under any conditions.

Tables & Chairs must be cleaned before returning or deposit will be kept for cleaning purposes.

OVERNIGHT RENTALS: Lessee understands and acknowledges that the blower is to be removed from the Inflatable device and locked up in a secure location overnight. INITIAL: _____

I, THE LESSEE, TAKE FULL RESPONSIBILITY FOR THE UNIT WHILE IN MY POSSESSION. ANY DAMAGES INCURRED TO THE UNIT WHILE IN MY POSSESSION WILL BE REASON FOR LOSS OF MY DEPOSIT. THE UNIT WILL BE RETURNED IN THE SAME CONDITION IT WAS RENTED IN. I HAVE READ AND UNDERSTAND THE TERMS SET FORTH WITH THIS CONTRACT:

SIGN _____ DATE _____

If K&M has to wait more than 15 minutes to begin setup because lessee is not at the location or were not prepared for setup then there will be a \$20 minimum charge for the first 15 minutes and then a \$20/hr. fee thereafter. INITIAL: _____

Contact Info

Name: _____ **Organization:** _____ **Cell #:** _____
Address: _____ **City:** _____ **State:** - _____
Zip: _____ **Email:** _____ **Surface Type:** - _____

Rented Equipment

- | | | |
|-----------|-----------|-----------|
| <u>1.</u> | <u>4.</u> | <u>7.</u> |
| <u>2.</u> | <u>5.</u> | <u>8.</u> |
| <u>3.</u> | <u>6.</u> | <u>9.</u> |

Delivery Date: _____ **Total Rent Amount:** _____
Delivery Time: _____ **Setup Amount:** _____
Event Start: _____ **Due at Delivery:** _____
Pickup Date: _____ **Deposit Amount:** _____
Pickup Time: _____ **Notes:** _____
Event End: _____ **# of units:** _____

Inflatable Air Bounce Instructions...

How to Set-up

- 1) Check ground for a flat level surface void of any rocks, sticks, pine cones, etc. (Anything that may puncture the bottom of the Inflatable). Also check height clearance for trees, power lines, or overhead obstructions. Tarps should be placed underneath all Inflatable's before proceeding to Step 2. (Never operate the Inflatable on a hard surface without under padding (i.e. tarp).)
- 2) Unroll the Inflatable in the direction you wish the Inflatable to face.
- 3) Unfold and Attach the Blower(s) to the "Port" (extended air hose / blower tube). The "Port" is generally located in the very back or on the sides of the Inflatable. Tie off any additional "Ports" by turning the material clockwise and tying the Port to itself. (Rope can also be used to close off additional Ports. Some Inflatable's allow you to tuck away additional ports).
- 4) Close All Velcro / Zipper compartments.
- 5) Attach heavy extension cord(s) from power source. (Designate One 20 amp fuse for each Blower. Generally, this equates to One 110-volt Outlet for each Blower.) Use 14 gauge or heavier extension cord(s) that extend No More than 100 feet from the Inflatable to the power source. (The lower the gauge number, the thicker the cord. Most household / garden extension cords are 16 gauge (Not Sufficient enough) and can harm the blower- reducing the air source to the Inflatable.)
- 6) Turn the Power on. (Some Blowers have an On/Off switch located on the blower.) While the Inflatable inflates- Check to make sure no air is escaping vents or ports.
- 7) Check to make sure the Port (air hose) leading to the Blower is not twisted.
- 8) Secure the Inflatable by staking the unit on all 4 corners. Drive stakes half way in at a 45 degree angle away from the inflatable. For larger Inflatables tie-outs will need to be staked.

Safety Instructions / Operation

- 1) Adult supervision is required at all times. Never leave the Inflatable unattended or unwatched.
- 2) Most Inflatables only allow 4-5 Guests on the Inflatable at a time. (Check Inflatable Instructions)
- 3) Guest must remove shoes, pocket items, glasses, jewelry, sharp objects, etc.
- 4) Diving and flipping are strictly prohibited. No back flips, roughhousing, horseplay or bouncing against walls. Guests should not take unnecessary risks.
- 5) No food, drink, gum, silly string or face-paint on or in the inflatable.

*The Inflatable should not be operated if winds exceed 20 mph.

*The Inflatable should not be used in rain or lightning conditions.

How to Takedown

- 1) Check for any loose items left on the Inflatable. (Sweep or vacuum where appropriate.)
- 2) All Guests should be clear of Inflatable- Including: stakes, flagging, weight bags, etc.
- 3) Turn Off or Unplug Blower. Disconnect the Blower from the Inflatable.
- 4) Open All Velcro / Zipper Flaps, Vents, and Ports to allow air to escape and the Inflatable to deflate. Deflation time varies on the Inflatable (10 – 20 minutes).

How to Roll an Inflatable

The Key to a Good Roll is to fold the material neatly in to the middle of the Inflatable.

- 1) Fold all material toward the middle of the Inflatable and find the bottom seams of the Inflatable.
- 2) Fold the Inflatable like a large bed sheet. Be sure to tuck all colorful designs inside your folds to avoid contact with the ground.
- 3) Fold sides in 2-3 feet lengthwise.
- 4) Continue to fold Inflatable from the outside-in until folded layers overlap leaving a fold of 2-3 feet.
- 5) Tuck in any extra material. (Leave Ports out to allow air to escape as you roll.)
- 6) Walk air out of the Inflatable by walking on the Inflatable towards the Port (Blower tube). (Doing so pushes air and allows air to escape.)
- 7) Where the Inflatable roll is to end- tuck in rope or strap 2-3 feet underneath Inflatable that is to be used for tying. (Doing so will allow you to not lift the entire roll to tie off.)
- 8) Begin rolling from the furthest point away from the Port (Blower tube). (Doing so pushes air to escape as you roll.) Roll as tightly as possible. Keep the roll lined up, tuck any in extra material, and do not allow any part of the roll to sag. Slack rolls are difficult to move. Take your time and roll it tight.
- 9) Tuck in Ports (Blower tubes).
- 10) Tie off roll with rope or strap. Tuck in hoses and any extra material. Place in bag when applicable. (Placing in a Bag: Turn Inflatable to a "standing position", pull bag from the top down to ground level. Rotate Inflatable in bag for transportation.)

Customer Name (print) _____ Customer Sign _____

Date: _____